


HEWLETT-PACKARD

82153A

WAND

OWNER'S MANUAL



"The success and prosperity of our company will be assured only if we offer our customers superior products that fill real needs and provide lasting value, and that are supported by a wide variety of useful services, both before and after sale."

Statement of Corporate Objectives
Hewlett-Packard

When Messrs. Hewlett and Packard founded our company in 1939, we offered one superior product, an audio oscillator. Today, we offer over 3500 quality products, designed and built for some of the world's most discerning customers.

Since we introduced our first scientific calculator in 1967, we've sold millions worldwide, both pocket and desktop models. Their owners include Nobel laureates, astronauts, mountain climbers, businessmen, doctors, students, and homemakers.

Each of our calculators is precision crafted and designed to solve the problems its owner can expect to encounter throughout a working lifetime.

HP calculators fill real needs. And they provide lasting value.

J. Mark Keller



HP 82153A
Stand Owner's Manual

August 1980

82153-90001 Rev. C

Contents

Introduction	5
Plugging the Wand Into the HP-41C	5
Removing the Wand From the HP-41C	6
Getting Started	6
How to Operate the Wand	6
Using the Paper Keyboard	7
Protecting Bar Code	8
Scanning Data Bar Code	8
Scanning Program Bar Code	9
Bar Coding Programs Using Pressure-Sensitive Labels	10
Wand Functions	11
WNDDTA	11
WNDDTX	11
WNDLNK	12
WNDSUB	13
WNDSCN	13
WNDTST	16
Customized ALPHA Prompts	17
Executing Programs Containing Wand Functions With No Wand Present	18
Appendix A: Errors and Messages	19
Appendix B: Maintenance and Service	23
Appendix C: Wand Accessories	29
Appendix D: Bar Code for the HP-41C Standard Applications Pac	31
Appendix E: Demonstration Programs	53
HP 82153A Wand Function Index	69

Introduction


The HP 82153A Wand enhances your HP-41C system by adding a new dimension to calculator control. The wand lets you take advantage of bar coded HP-41C programs, data, and even individual HP-41C calculator functions. So that you can fully use the wand's capabilities in your HP-41C system, take time to work through the few pages in this manual. You will find the wand simple to operate, yet useful in a wide range of applications.

Plugging the Wand Into the HP-41C


1. Make sure the HP-41C is turned off.



2. Remove the port cap from any unused port. (The wand should always be plugged into a higher numbered port than any memory modules you may be using.)




3. Insert the wand interface module into the empty port. Push it into the calculator until it snaps firmly in place.



Removing the Wand From the HP-41C

1. Turn off the HP-41C!



2. Pull the wand interface module straight back until it is clear of the port. Do not pull on the cord.



3. Replace the port cap.


Getting Started

Part of the wand's uniqueness among calculator products is the degree to which you directly control factors that determine wand performance. The rate and consistency of your scan speed, the angle and constancy of tilt you maintain, and your ability to keep the wand tip within the top and bottom edges of the bar code rows all influence your results with the wand. Still another factor that impacts wand performance is the quality of the bar code itself. Well-defined bar images that contrast sharply with the print medium produce the best results. Worn, damaged, or poorly printed bar code can hinder or prevent successful wand use.


How to Operate the Wand

The bar patterns in HP-41C bar code rows are coded forms of programs, data, or functions. The information in the bar code is read into the calculator by scanning the bar code with the tip of the wand. Although you can scan in either a left to right or right to left direction, you may notice slightly better results using the left to right scan direction.


1. Hold the wand in a comfortable position. The wand performs best when tilted between 10° and 20° in any direction.



2. Press the recessed scan switch and lightly place the wand tip on the paper. The tip should be placed about 1 cm (approx. 0.4 in.) from the first bar in the row.




3. Scan the bar code at a rapid and uniform speed. (Avoid the tendency of many new users to scan too slowly, which can prevent the wand from processing the bar code.)



4. Keep the wand tip in continuous contact with the paper until you scan past the last bar in the row. If you are new to wand-type devices, you may experience scan errors frequently the first few times you use the wand. However, taking some time to practice scanning bar code will help you develop a scan technique that achieves satisfactory results.

Note: To conserve battery power, keep the scan switch pressed only while you are scanning a row of bar code.



After each scan the HP-41C normally responds by sounding a short *scan tone*. But if the system detects an error condition during a scan, the HP-41C responds instead with a prolonged *scan error tone* and, in most cases, a displayed error message. Appendix A, Errors and Messages, describes error conditions and error recovery. If the HP-41C does not respond to a scan, check your scan angle and rescan the row more carefully.

Using the Paper Keyboard

The Wand Paper Keyboard contains bar code that allows you to execute the individual functions resident in the HP-41C and its peripherals.* Each function is scanned as a separate row, allowing you to use the wand for executing system functions you would otherwise execute from the keyboard.

Example: Scan the following bar code to execute the indicated functions. (The example assumes a **FIX 4** display setting.)

HP-41C	Paper Keyboard	Display
Function	Bar Code	
PI		3.1416
STO		STO__
0		STO 0__

*The HP 82104A Card Reader, the HP 82143A Printer, and the HP 82153A Wand.

HP-41C Function	Paper Keyboard Barcode	Display	
1		3.1416	Pi stored in R ₀₁ .
CLX		0.0000	Clears display.
RCL		RCL __	
0		RCL 0 __	
1		3.1416	Recalls pi to display.
CLX		0.0000	Clears display.

You may want to experiment further with the paper keyboard by executing functions you use often, or by scanning the bar coded ALPHA characters needed to spell your name. If you use certain portions of the paper keyboard frequently, you may want to try using some of the pressure-sensitive bar code labels included with your wand to construct a personalized paper keyboard layout.




Note: You can initiate the assignment of a function to an HP-41C keyboard location using the wand and paper keyboard. However, to complete the operation, you must press the HP-41C key to which you want the function assigned.

Protecting Bar Code

Without protection, bar code will wear with use. To protect your bar code, place one of the transparent sheets you received with the wand over the bar code, glossy side down, before you begin scanning. If you want to use other types of protective coverings for your bar code, choose those that will not present a glossy surface to the wand tip. A glossy surface may cause reflections that can reduce the wand's ability to read the bar code you are scanning.

Scanning Data Bar Code

When you scan a row of data bar code, the data is entered in the HP-41C in the same manner as when you enter data from the keyboard. Scan the following bar code to enter the approximate speed of light in kilometers per second.

Bar Code	Display	Stack
 299,792.5	299,792.5000	T  Z  Y  X 


Scanning two or more rows of numeric data in sequence affects the stack in the same way as keying in two or more numbers.

Bar Code	Display	Stack								
	6.1413	<table border="1"> <tr><td>T</td><td></td></tr> <tr><td>Z</td><td></td></tr> <tr><td>Y</td><td>299,792.5000</td></tr> <tr><td>X</td><td>6.1413</td></tr> </table>	T		Z		Y	299,792.5000	X	6.1413
T										
Z										
Y	299,792.5000									
X	6.1413									
	299,792.5000	<table border="1"> <tr><td>T</td><td></td></tr> <tr><td>Z</td><td></td></tr> <tr><td>Y</td><td>6.1413</td></tr> <tr><td>X</td><td>299,792.5000</td></tr> </table>	T		Z		Y	6.1413	X	299,792.5000
T										
Z										
Y	6.1413									
X	299,792.5000									
	0.0000	<table border="1"> <tr><td>T</td><td></td></tr> <tr><td>Z</td><td></td></tr> <tr><td>Y</td><td>6.1413</td></tr> <tr><td>X</td><td>299,792.5000</td></tr> </table>	T		Z		Y	6.1413	X	299,792.5000
T										
Z										
Y	6.1413									
X	299,792.5000									
		First data entry. Second data entry.								
		Contents of X- and Y-registers exchanged.								
		Clears the display.								

To load bar coded numeric or ALPHA data as lines in program memory, set the HP-41C to PRGM mode, then scan the data bar code. Numeric data is stored in program memory as a numeric entry. ALPHA data is stored in program memory as an ALPHA string.

Scanning Program Bar Code

HP-41C program bar code is listed in the following format:



The occurrence of program line number 6 twice, i.e., at the end of row 1 and at the beginning of row 2, indicates that the bar code for the function on program line 6 is divided between the two rows.

To load a bar coded program into your HP-41C:

1. Ensure that there is enough space in program memory to load the program. (The number of registers required to store the program is printed above the first row of bar code.)
2. Scan the rows of program bar code sequentially, beginning with row 1. After each row is scanned, the calculator should sound the scan tone and prompt you for the next line with:

W: RDY nn

where **nn** is the number of the next bar code row to be scanned.

If the HP-41C sounds the scan error tone while you are scanning program bar code, refer to appendix A, Errors and Messages.

After you scan the last row of program bar code, the message **W: WORKING** temporarily appears in the display, then the normal display reappears. (The HP-41C is set to line 01 of the program.) Scanning a new program clears the last program in memory. However, if you want to append the new program to those already in memory, execute **GTO** before scanning the new program.



Example: The following bar coded program calculates the volume of a cylindrical tank given the tank's diameter and length. Using the procedure described above, load the program into your HP-41C.

PROGRAM REGISTERS NEEDED: 9

ROW 1 (1 - 3)



Display W: RDY 02

ROW 2 (3 - 9)



Display W: RDY 03

ROW 3 (10 - 14)



Display W: RDY 04

ROW 4 (15 - 18)



Display W: RDY 05

ROW 5 (18 - 20)



Display: W: WORKING, then 0.0000.

Ensure that the HP-41C is not in PRGM mode, then use the following bar code to execute the program to calculate the volume in cubic meters of a tank 3.4 meters in diameter and 4.6 meters long.*

Bar Code



XEQ VOL



3.4




4.6



CLX

Display

DIAMETER?



LENGTH?

VOLUME = 41.8

0.0000

Clears the display.

A program scan session can be terminated early by pressing the **■** or **R/S** keys. The partially loaded program is left in memory.

Bar Coding Programs Using Pressure-Sensitive Labels

Pressure-sensitive bar code labels are available for every function built into the HP-41C and its peripherals. Using these labels you can save time by having immediate access to the bar code you need rather than having to wait for bar code produced through other sources. Pressure-sensitive labels are particularly useful when you want to rapidly



*This program assumes flag 21 (printer enable flag) is cleared if the printer is not plugged in.

assemble bar coded program listings or create customized HP-41C configuration instructions for your own unique applications.

Using Pressure-Sensitive Labels. Where labels are to be used to load program bar code, first write and check your program to reduce the chances of having to make later changes. Then, one by one, remove the needed labels from the label sheets and apply them to a worksheet. Avoid creases in the labels as the wand may detect them in the bar code and respond with an error condition.

Layout and Scanning. Because each label is processed individually by the wand, a row of bar code labels cannot be scanned as rapidly as a row of standard program bar code. For this reason, ensure that the scan tone indicating a good read, sounds after each label is scanned. If you find it difficult to maintain a comfortable speed while scanning labels in a row format, try a columnar format. Scanning labels in a column normally allows the wand sufficient time between scans to prevent any errors due to insufficient processing time.

One of the protective transparent sheets you received with the wand should be placed over any set of labels you are going to scan. The transparent sheet will protect the labels and reduce the possibility of the wand reading label edges as bars and causing an error condition.



Wand Functions

The wand functions are contained in the wand circuitry and become active in the HP-41C system whenever the wand is plugged into the HP-41C. Wand functions may be executed manually or under program control in the same manner as other HP-41C functions. All can be terminated early by pressing the **■** or **R/S** keys.

WNDDTA

The **WNDDTA** (*wand data*) function halts a running program to let you input a single row of numeric or ALPHA data. When **WNDDTA** is executed, the HP-41C prompts you by displaying

W: SCAN DATA

After you scan a row of data bar code, program execution resumes.

WNDDTX

The **WNDDTX** (*wand data by x*) function, like **WNDDTA**, halts a running program to let you scan data bar code. However, under **WNDDTX** control, you can load an entire set of data directly into one or more of the HP-41C's storage registers. **WNDDTX** uses the data control number you place in the X-register to specify the storage registers to be used.

How **WNDDTX** works:

1. Using the following format place a data control number into the X-register.

bbb.eee

bbb is the beginning (lowest numbered) data storage register address used and **eee** is the ending (highest numbered) data storage register address used. The **bbb** portion can be less than three digits. The **eee** portion *must* be three digits. The absolute value of **bbb.eee** is used to select the series of consecutively numbered data storage registers in which to store the data. For example, when using **WNDDTX** with 10.020 in the X-register, the calculator stores data in 11 registers, R_{10} through R_{20} .

2. Execute **WNDDTX**. The HP-41C then prompts you to scan the data bar code rows, one at a time, by displaying

W: SC TO nn

nn is the storage register to receive the data from the next row of data bar code you scan. Each time you scan a data bar code row, **nn** automatically increments by one. When data has been stored in all registers specified by **bbb.eee**, program execution resumes.

When using **WNDDTX** to load data into only one register, simply enter that register address as **bbb** and omit the **eee** portion of the data control number.

WNDLNK

The **WNDLNK** (*wand link*) function causes the calculator to halt program execution so that you can use the wand to load and automatically execute a new subroutine. If the new subroutine terminates with a **RTN** instruction, the HP-41C will then automatically resume execution of the original program. The new subroutine you scan replaces the last program in memory* unless one of the following conditions applies:

1. The executing **WNDLNK** instruction is in the last program in memory, or
2. **WNDLNK** is executed manually while the calculator is positioned to the last program in memory.


When **WNDLNK** is executed, the HP-41C prompts you with

W: SCN SUBLNK

After you scan the first row of the new subroutine, the HP-41C begins to prompt you in the same manner as other program bar code scans, i.e., with **W: RDY nn**.

Main Program

New Program or Subroutine



1. The HP-41C halts execution and prompts you with **W: SCN SUBLNK**.
2. You scan the new subroutine.
3. The HP-41C automatically executes the new subroutine.
4. The HP-41C automatically resumes execution of the main program.

* Executing **GTO** **■** **■** before executing **WNDLNK** protects all programs currently in memory from being cleared by the new subroutine.


WNDSUB

The **WNDSUB** (*wand subroutine*) function halts program execution so you can use the wand to scan a new subroutine. **WNDSUB** operates in the same manner as **WNDLNK**, except:

1. When **WNDSUB** is executed, the HP-41C prompts you with

W: SCAN SUB

2. After the new subroutine is scanned, program execution resumes with the first instruction in program memory after the **WNDSUB** instruction.



WNDSCN

The **WNDSCN** (*wand scan*) function is designed for use in specialized applications involving control of the HP-41C system through unique patterns of user-created bar code. If you are new to the HP-41C system or to the more technical aspects of bar code design and generation, you may want to bypass this topic until a later time.

Use of **WNDSCN** involves:

1. Producing your own specialized HP-41C bar code or using the specialized labels included in the pressure-sensitive label set shipped with your wand.* Instead of translating your bar code into HP-41C functions or data, the wand converts the binary (base two) value of each byte (set of eight bars) of your specialized bar code into the decimal (base 10) equivalent and stores this equivalent in one of the HP-41C's data storage registers.
2. Creating an HP-41C program that will use the decimal equivalent outputs from **WNDSCN** for selecting pre-determined functions, operations, or whole routines.

* The label set shipped with your wand includes a series of one-byte labels identified with a number between 1 and 64. Each number is the decimal equivalent of the binary value of the bar code printed on the label.

Example: A game of checkers using the wand could employ the following short program to convert wand inputs into displayed coordinates of positions on the board.

LBL SQR
FIX 0
CF 29

WNDSCN } Converts the single byte of binary bar code data for the square that was scanned into decimal data and stores the converted data in **R₀₁**.

RCL 01
10
+
INT
ALPHA ROW
 SPACE **ALPHA**
ARCL X } Identifies the square's row number and places it in the ALPHA register with a **ROW** label.

RCL 01
10
MOD
ALPHA APPEND
,
 SPACE
COL SPACE
ALPHA
ARCL X } Identifies the square's column number and appends it with a **COL** label, to the row data in the ALPHA register.

AVIEW } Displays the decimal coordinates of the selected square.
FIX 4
SF 29
RTN

Load and execute the program using the following bar code. Then scan the bar code in a square of the checkerboard illustration on the next page and view the corresponding square identification in the HP-41C's display. (The bar code row in each square consists of the binary equivalent of a two-digit decimal number that identifies the square by row and column.) The above program could be modified to make the data from the squares available for other operations as well.

PROGRAM REGISTERS NEEDED: 7

ROW 1 (1 - 4)



Display W: RDY 02

ROW 2 (5 - 11)



Display W: RDY 03

ROW 3 (12 - 15)



Display W: RDY 04

ROW 4 (16 - 20)



Display W: WORKING, then 0.0000. (Assumes a **FIX** 4 display that was cleared before the program was scanned.)

Ensure that the HP-41C is not in PRGM mode. Then execute SQR by scanning the following bar code:


Bar Code**XEQ SQR**

Scan the square in the upper left corner of the following illustration.

Display**W: READY****ROW 1, COL 1**

Identifies the row and column of the square you scanned.


To scan another square and view its position, reexecute SQR.



(You can use the set of numbered, one-byte labels included in the HP-41C bar code labels shipped with your wand for identifying locations in an 8×8 matrix.)

How to use **WNDSCN**:

1. Ensure that there are enough data storage registers available in the HP-41C for the number of bytes (sets of eight bars) in the row you will scan under **WNDSCN** control. Beginning with R_{01} , **WNDSCN** uses one data storage register for each byte in the row. A row can be as short as one byte (8 bars), or as long as 16 bytes (128 bars).



Note: Because the first and last pairs of bars in a row indicate scan direction, every row of bar code must also include the illustrated directional bars.


2. Execute **WNDSCN**. The HP-41C will prompt you to scan a row of your bar code by displaying

W: READY


3. Scan the desired row.

After you scan a row of your bar code, the HP-41C's registers are loaded as follows:

1. The total number of bytes read (n) is placed in the HP-41C's X-register as a normal digit entry.



2. The decimal equivalent (yyy) of the binary value of each byte is placed sequentially in the HP-41C's data storage registers. The value of the first byte is placed in R_{01} . The value of the last byte is placed in R_n (where n is the value placed in the X-register in step 1, above).



With the decimal form of the byte values in the HP-41C's data storage registers, the **WNDSCN** operation is complete. The values can now be accessed and interpreted according to your instructions.

If you execute **WNDSCN** in a running program, program execution resumes with the first instruction in program memory following the **WNDSCN** instruction. Note that under **WNDSCN** control the wand cannot perform the error checking it performs during other wand operations (refer to appendix A, Errors and Messages). However, you can design your own error tests in the programs you write for use with **WNDSCN**.

WNDTST

The **WNDTST** (*wand test*) function lets you test the wand or any HP-41C bar code by displaying what has been read in a row you scanned. To use this test, execute **WNDTST** and scan a row of bar code. Then note and compare each set of digits returned in the HP-41C's display with the corresponding bar pattern in each consecutive byte of eight bars in the row. The narrow and wide bars correspond to 0's and 1's in the display, i.e.,



Note: Because the first and last pairs of bars in a row indicate scan direction, they are not displayed by **WNDTST**.

Example: Use **WNDTST** to test a copy of the above bar code. Because **WNDTST** uses R_{00} as a counter, plus one storage register for each byte in a row, be sure that data registers R_{00} through R_{02} are available for this example. To run the test, scan the following bar code.

Bar Code



Test Bar Code



CLX

Display

W: READY

Executes **WNDTST**.

B1. = 1.1.0.1.0.1.0.0.

Corresponds to the pattern of the wide and narrow bars in the first byte:



11010100

B2. = 0.0.0.0.1.0.0.1.

Corresponds to the pattern of the wide and narrow bars in the second byte:



00001001

0.

Clears display. (**WNDTST** sets the display to **FIX** 0 and clears the stack of any previous data.)

Note: If flag 29 is cleared you will not see the radix marks (refer to page 230, Display Control Flags, in the *HP-41C Owner's Handbook and Programming Guide*).

If the wand correctly reads the bar code you scan, the displayed zeros will correspond to the narrow bars and the displayed ones will correspond to the wide bars. A series of consistent misreads of a bar code row normally indicates defective bar code. However, if the wand consistently misreads bar code that is in good condition, the wand may need service. If you suspect that your wand is operating improperly, refer to appendix B, Maintenance and Service.

How It Works. When you execute **WNDTST** and scan a row of bar code, the value of each consecutive byte in the row is stored in a separate data storage register. Because the wand is designed to handle rows up to 16 bytes long, you will never need more than R_{00} through R_{16} for any **WNDTST** operation. The byte values will always be displayed in the left-to-right sequence that the corresponding bytes occur in the row, regardless of your direction of scan.

Programming **WNDTST**. As you would expect, **WNDTST** is loaded into program memory in the same way as other HP-41C functions. However, unlike the other wand functions, **WNDTST** is actually an HP-41C applications program that calls a wand function (**WNDSCN**). For this reason, when you scan **WNDTST** or key in **XEQ** **WNDTST** with the HP-41C in PRGM mode, the instruction appears in program memory as

XROM T WNDTST

*


WNDTST Options. If you use an HP 82143A Printer with your HP-41C, executing **WNDTST** will result in an automatic printout of the displayed byte values. If you do not use a printer, but want the HP-41C to halt for each byte value display instead of pausing, set flag 21 before executing **WNDTST**. After the first byte value appears, execute **R/S** each time you are ready to step from one byte value display to the next.

Customized ALPHA Prompts

Using the following programming procedure you can replace initial **WNDDTA**, **WNDDTX**, **WNDSUB**, **WNDLNK**, **WNDSCN**, or **WNDTST** function prompts with your own customized ALPHA prompts.

* If **WNDTST** has been copied into program memory first, placing the HP-41C in PRGM mode, then scanning or keying in **XEQ** **WNDTST** results in **XEQ T WNDTST** appearing as an instruction in program memory.

Program Memory



Program lines 03 through 05 and 11 through 13 of the program on page 10 show an example of this usage.

Executing Programs Containing Wand Functions With No Wand Present

Remember from the beginning of this section that the wand functions only become available while the wand is plugged in. So if you have programs stored in program memory that contain specific wand functions, and the wand is not attached, those wand functions are nonexistent and that program will not execute properly (when a wand function is encountered, the display will show **NONEXISTENT**). However, when you plug the wand back in and execute that program, it will execute properly. Here is how the HP-41C keeps track of these wand functions:

1. While the wand is in place, the function name appears normally in program memory, like this: **18 WNDDTA**, or **27 WNDSub**.
2. While the wand is removed, these functions are displayed in PRGM mode as a function called **XROM**. An **XROM** function tells the HP-41C that the function belongs to some plug-in accessory. Next to the **XROM** function name are two numbers. These numbers indicate which accessory the function belongs to as well as an indicator of the function. So, the program line **18 WNDDTA** (with the wand plugged in) would change to **18 XROM 27,01** while the wand was removed. The **XROM** tells the system that the function belongs to a plug-in accessory, and the **27,01** tells the system that that accessory is number **27** (the wand) and the function number is **01** (**WNDDTA**).

Programs containing these functions have the following XROM numbers while the wand is removed:

Function	XROM Number
WNDDTA	XROM 27,01
WNDDTX	XROM 27,02
WNDLNK	XROM 27,03
WNDSub	XROM 27,04
WNDSCN	XROM 27,05
WNDTST	XROM 27,06

Errors and Messages

Scan Error Conditions

Most scan errors are caused by slow or uneven scanning, inaccurate scans, i.e., missing some of the bars in a row, excessively tilting the wand, or by defective bar code. When the wand detects a scan error condition, the HP-41C sounds the prolonged scan error tone, and, in most cases, displays an error message. Bar coded information from the row causing the scan error is rejected, and no information transfer or function execution takes place.* To hear the difference between the normal scan tone and the scan error tone, scan the following rows of paper keyboard bar code. Scanning the row of good bar code gives you the normal scan tone and causes the indicated function to be executed. Scanning the meaningless bar code consistently produces the scan error tone. Scanning the defective paper keyboard (or label) bar code can result in no response, a scan error indication, or, in some cases, the wrong function.



ON (Disables automatic turn-off.)



ON (Disables automatic turn-off.)

You can reduce scan errors to a minimum by developing a good scanning technique and by protecting your bar code. When you experience scan errors that are not due to defective bar code, you can normally recover by simply rescanning the rejected row. But if the error condition persists, you may want to execute the **WNDTST** function (refer to page 15, **WNDTST**). If **WNDTST** indicates wand read failures and the bar code is not worn or poorly printed, refer to appendix B, Maintenance and Service.

Direct sunlight overloads the wand's light sensor sufficiently to hinder or prevent the wand from reading bar code. For this reason, if you operate the wand in direct sunlight, shield the bar code you are scanning.

Error Messages

W: ADDR ERR **Address error.** An attempt was made to store data in a nonexistent data storage register.

Recovery: You may want to use **SIZE** to create more storage register space or store the data in another, existing storage register. If you interrupt a **WNDDTX** operation to create more storage registers or change **bbb.eee**, reexecute the entire operation.

W: CKSUM ERR **Checksum Error.** The system has detected a scan error or program barcode sequence error.

Recovery: Paper keyboard or data barcode. Re-scan the row where the error condition occurred. If repeated scan errors occur, the barcode may be defective. Enter the function or data from the keyboard. If data entry was under **WNDDTA** or **WNDDTX** control, do the following:

1. Press the **—** key to terminate the **WNDDTA** or **WNDDTX** function.
2. Enter from the keyboard all remaining data in that series to avoid any storage errors.
3. If the error occurred in a running program, execute **R/S** to resume program execution.

Recovery: Program barcode.

1. Check the display prompt to be sure you scanned the proper row. Scan the row indicated by the prompt.

*Most bar code types use a checksum to detect errors, e.g., the checksum in program bar code causes an error message if the bar pattern is misread. However, with the short rows and similar patterns in *paper keyboard* and *label* bar code, it is possible that a row coded as one function can be misread and accepted as another function. In most cases this condition is due to defective bar code or use of improper scan techniques.

2. If the checksum error condition persists, bypass the row by pressing the **SST** key. The display will then prompt for the row following the bypassed row and you can continue scanning the program. (If the error condition occurs in the last row of bar code in a program, press **□** instead of **SST**.) After you scan the last row of the program, identify the bypassed program instructions by comparing the program in the HP-41C with a written listing of the same program. (Where the printed program line numbers indicate that a numbered program instruction begins on a row you scanned and ends on a row you bypassed, that entire program instruction is bypassed.) Then go to the place in program memory where the missing instructions belong and load them using the paper keyboard or the HP-41C's keyboard.

Note: The system uses a running checksum to monitor program bar code rows for scan errors. When you bypass a row of program bar code and resume scanning with the following row, the checksum monitoring system assumes that the row scanned after the bypassed row was correctly read. When you scan the second row after the bypassed row, normal running checksum monitoring is reinitialized to the correct running value. For this reason you should compare the instructions in program memory with a listing of the program to be sure the series of instructions in the row following the bypassed row were read correctly.



W: DATA ERR **Data error.** The data just scanned is out of the calculator's range, or there is an illegal character recorded in the data barcode line.

Recovery: Enter the data from the keyboard. If **W: DATA ERR** occurs during a **WNDDTX** operation, enter from the keyboard all data beginning with the data in the line that will not read. (Refer to **W: CKSUM ERR** information for the correct procedure.)

W: NO ROOM **PACKING** **TRY AGAIN** **Memory Filled.** There is insufficient space in memory to load the current line of program instructions or key reassignments.

Recovery: Create more space in memory, then rescan the program from the beginning, or resume your key assignment operations.

W: SEQ ERR **Sequence error.** Occurs only if you bypass a row of program bar code using **SST**, then scan a row other than the row indicated in the display by **W: RDY nn**.

Recovery: Scan the row indicated by **W: RDY nn**.

W: TYPE ERR **Type error.** An unexpected type of barcode has been scanned.

Recovery: Complete or terminate the previous operation before proceeding to the new type.

Procedural Messages

W: RDY nn The wand is ready to scan program barcode row **nn**.

W: READY The wand is waiting to scan.

W: SC TO nn Follows execution of the **WNDDTX** function. Scan the row of data barcode you want stored in data storage register **nn**.

W: SCAN DATA Follows execution of the **WNDDTA** function. Indicates the wand is ready to scan a single row of data barcode. Numeric data will be placed in the X-register; ALPHA data in the ALPHA register.

W: SCN SUBLNK The prompt following execution of the **WNDLNK** function. Scan the desired subroutine.

W: SCAN SUB The prompt following execution of the **WNDSUB** function. Scan the desired program or subroutine.

Maintenance and Service

CAUTION

Always turn off the HP-41C before inserting or removing the wand interface module. Failure to turn off the HP-41C could damage both the calculator and the wand.

Specifications

Power

Draws less than 50 mA at 5V from the HP-41C's batteries when the scan switch is pressed (HP-41C turned on or off).

The wand's cumulative effect on the HP-41C's batteries varies with the frequency and duration of use, but can be significant with heavy use. (If the scan switch is continuously pressed, a new set of batteries in the HP-41C will last approximately 10 hours.)

Scan Angle and Distance

Up to 25° from the vertical with tip in contact with bar code medium (the optimum scan angle is 10° to 20°).

Temperature and Altitude

Operating 0° to 45°C 32° to 113°F

Storage -20° to 65°C -4° to 149°F

25,000 feet maximum (non-pressurized cabin)

Wand Care

While there are no user-serviceable parts inside the wand, observing the following precautions will help ensure long term satisfactory performance.

CAUTION

Do not use spray cleaner on the sensor or the wand. If you spray any liquid on the wand or wand parts, damage may result.

1. Keep the electrical contact areas of the wand interface module and calculator module ports free of obstructions. Should the contacts become dirty, carefully brush or blow the dirt out of the contact area. Do not use any liquid to clean the contacts.
2. Check the aperture in the wand tip periodically for dirt or obstructions. If it is necessary to clean the tip, first turn off the HP-41C and remove the wand from the calculator. Then unscrew the tip from the wand body. The aperture can be cleared with a cotton swab or similar device and a liquid detergent. The glass window on the sensor should be inspected and cleaned if dust, dirt, or fingerprints are visible. To clean the sensor window, dampen a lint free cloth with liquid glass cleaner and clean the window with the cloth.

Take care not to disturb the positioning of the sensor or damage the sensor assembly while the wand tip is off for cleaning. After cleaning the aperture and sensor window, the tip should be gently and securely screwed back into the wand.

3. Store the wand in a clean, dry place. Static electricity could damage the wand's circuitry.
4. Always turn off the HP-41C before inserting or removing the wand interface module. Failure to do so could damage both the calculator and the wand.

CAUTION

Do not insert your fingers or any objects other than an HP module or plug-in accessory into any port. To do so could alter the Continuous Memory or damage the port or the calculator. Always keep the port caps in place over any module ports you are not currently using.

A Word About Bar Code

Bar code is a combination of bars and spaces formatted to represent various types of information. Three parameters that help determine readability are contrast ratio between the bars and spaces, space width, and wear or print quality of the bars. Because the use of color in bar code can reduce the contrast ratio between bars and spaces, it is recommended that you use only black bar code printed on white surfaces. Error in space width can result from the distortion introduced to some degree by most copying machines. Depending upon the degree of distortion present, this may noticeably affect the bar code you copy. Your copies should have a narrow bar width and spacing of no less than 15 mils. Wear or poor print quality may introduce frequent errors and can render the bar code unreadable. Here are some examples of worn bar code and bar code of poor print quality.



Copying Bar Code

Most typical office copiers do not reproduce bar code well. Poor bar resolution, reduced bar width, and stray marks are the most frequently encountered problems. These problems can be minimized by using a copier that produces a very dark image with sharp resolution. When copying bar code label materials, it is best to use a machine with a "pasteup" mode to avoid reproducing the edges of the labels on the copy. The wand may detect such images and produce an error condition. In most cases, reliable copies cannot be made from other copies.

As you may have noticed, the photo mechanisms in copy machines move in either side-to-side or top-to-bottom motion. The sharpness of resolution in your copies of bar code may vary with the direction of this motion across the originals you copy from. If the bars in your copies are not sharply defined, try copying the material with the originals turned 90° on the copy surface. If the copier you have access to does not reproduce bar code well, you may want to try the alternative of having your bar code reproduced through an offset printing process.

Protecting Bar Code

When scanning bar code, remember that the wand should be used with a light touch. Applying pressure only increases wear. Because most bar code will wear rapidly if unprotected, you should always cover bar code you are scanning with one of the transparent sheets provided with the wand. Another method of protecting bar code is to cover it permanently with a non-glossy, transparent adhesive tape. If bar code you are using becomes smeared, creased, or smudged, it should be replaced.

Improper Wand Operation

If the HP-41C operates, but fails to respond properly when you scan bar code, do the following:

1. Ensure that any failures are not due to faulty bar code. Examine the bar code for signs of wear or obvious defects that would affect readability. Test the wand using **WNDTST** or by scanning several bar code rows that are in good condition.
2. Check for the **BAT** annunciator in the display. If **BAT** is displayed the batteries may not be providing adequate power and may cause the wand to operate improperly. Refer to appendix B, Maintenance and Service, in your *HP-41C Owner's Handbook and Programming Guide*.
3. Be sure you are operating the wand according to the instructions in Getting Started, page 6.
4. Be sure the wand tip is securely screwed into the wand.
5. Check the red read light in the wand tip. Be sure that the scan switch turns the light on *and* off. Turn off the HP-41C, unplug the wand interface module, plug the module back in and turn on the HP-41C. Then operate the wand. Also try operating the wand with the interface module plugged into a different port, and/or try operating another peripheral using the original wand module port.
6. Execute the **WNDTST** function (refer to page 15).
7. Examine the HP-41C's module ports and wand module contacts for obstructions or damage.
8. If you are unsure as to the source of the problem, you may want to take your HP-41C and the HP 82153A Wand to your nearest authorized HP retail dealer prior to sending the unit in for service. By temporarily exchanging the wand or calculator and operating the system, you and your dealer may be able to determine which device is not functioning properly. Only the device that has been determined to be malfunctioning should be sent to HP for service. If you and the dealer are unable to determine the source of the malfunction, send both the HP-41C and the HP 82153A Wand to HP for service. Refer to Service, page 26.

Note: The wand reads bar code using a photosensor to detect light reflected from the bar code. Because of the low intensity of the reflected light signal, highly sensitive circuitry has been built into the wand. Due to this sensitivity, the wand can be affected by nearby strong electrical or magnetic fields (such as those caused by power cords, electric machinery, or electric power lines). Any magnetic or electrical interference occurring in the wand will result in "no read" or "read error" conditions. Using a recharger in the HP-41C system while operating the wand can cause interference conditions. If there is recharger interference, it can sometimes be reduced by reversing the recharger plug in its socket. Read problems due to interference can also be reduced by ensuring that you do not grasp the wand near the tip, where the wand's sensitive circuitry is located, and by scanning the bar code at a different angle.

Limited One-Year Warranty

What We Will Do

The HP 82153A Wand is warranted by Hewlett-Packard against defects in materials and workmanship for one year from the date of original purchase. The wand is designed and warranted to read only bar code that is within Hewlett-Packard's specifications for HP 82153A Wand bar code. (Refer to *Creating your own HP-41C Bar Code*.) If you sell your wand or give it as a gift, the warranty is automatically transferred to the new owner and remains in effect for the original one-year period. During the warranty period, we will repair or, at our option, replace at no charge a product that proves to be defective, provided you return the product, shipping prepaid, to a Hewlett-Packard repair center.

What Is Not Covered

This warranty does not apply if the wand has been damaged by accident or misuse, or as a result of service or modification by other than an authorized Hewlett-Packard repair center.

No other express warranty is given. The repair or replacement of a product is your exclusive remedy. **ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS IS LIMITED TO THE ONE-YEAR DURATION OF THIS WRITTEN WARRANTY.** Some states, provinces, or countries do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. **IN NO EVENT SHALL HEWLETT-PACKARD COMPANY BE LIABLE FOR CONSEQUENTIAL DAMAGES.** Some states, provinces, or countries do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state, province to province, or country to country.

Warranty for Consumer Transactions in the United Kingdom

This warranty shall not apply to consumer transactions and shall not affect the statutory rights of a consumer. In relation to such transactions, the rights and obligations of Seller and Buyer shall be determined by statute.

Obligation to Make Changes

Products are sold on the basis of specifications applicable at the time of manufacture. Hewlett-Packard shall have no obligation to modify or update products once sold.

Warranty Information Number (In the U.S. only)

If you have any questions concerning this warranty please call toll-free (except in Alaska, Hawaii, and Oregon) 800/547-3400. In Oregon call 757-2000.

Service

How To Obtain Repair Service

Hewlett-Packard maintains repair centers in most major countries throughout the world. You may have your wand repaired at a Hewlett-Packard repair center any time it needs service, whether the unit is under warranty or not. There is a charge for repairs after the one-year warranty period. Please refer to shipping instructions.

In the United States

The Hewlett-Packard United States Repair Center for handheld and portable printing calculator products is located in Corvallis, Oregon. The mailing address is:

**HEWLETT-PACKARD COMPANY
CORVALLIS DIVISION SERVICE DEPARTMENT
P. O. BOX 999/1000 N.E. CIRCLE BLVD.
CORVALLIS, OREGON 97330
U.S.A.**

In Europe

In Europe, returns should be made to the nearest Hewlett-Packard designated collection point or service center. Contact your HP authorized dealer directly for assistance.

A Hewlett-Packard designated service center is maintained in most European countries.

International Service Information

Not all Hewlett-Packard repair centers offer service for all models of HP calculator products. However, if you bought your wand from an authorized Hewlett-Packard dealer you can be sure that service is available in the country where you bought your wand.

If you happen to be outside of the country where you bought your wand, you can contact the local Hewlett-Packard repair center to see if HP 82153A Wand service is available. If service is unavailable, please ship your wand to the address listed under "In the United States," above. A list of repair centers for other countries may be obtained by writing to the above address.

All shipping, reimportation arrangements, and customs costs are your responsibility.

Hewlett-Packard calculator products are normally repaired and reshipped within five (5) working days of receipt at any repair center. This is an average time and could possibly vary depending upon the time of year and work load at the repair center.

The total time you are without your wand will depend largely on the shipping time.

Service Repair Cost

There is a fixed repair charge for out-of-warranty repairs. The repair charges include labor, material, and all return shipping charges. In the United States, the full charge is subject to the customer's local sales tax.

Calculator products damaged by accident or misuse are not covered by the fixed repair charges. In these situations repair charges will be individually determined based on time and material.

Service Warranty

Any out-of-warranty repairs performed are warranted against defects in materials and workmanship for a period of 90 days from date of service.

Shipping Instructions

Should your HP 82153A Wand require service, return it with the following items:

1. A completed Service Card, including a description of the problem.
2. A sales receipt or other proof of purchase if the one-year warranty period has not expired.

The wand, Service Card, and (if required) the proof of purchase should be packaged in the original shipping case or other adequate protective packaging to prevent in-transit damage. Such damage is not covered by the one-year limited warranty; Hewlett-Packard suggests that you insure the shipment to the repair center. The packaged wand should be shipped to the nearest Hewlett-Packard designated collection point or service center. Contact your dealer directly for assistance. (If you are not in the country where the wand was originally purchased, refer to International Service Information on page 26.)

Whether the unit is under warranty or not, it is your responsibility to pay shipping charges for delivery to the Hewlett-Packard repair center.

After warranty repairs are completed, the repair center returns the unit with postage prepaid. On out-of-warranty repairs in the United States and some other countries, the unit is returned C.O.D. (covering shipping costs and the service charge).

Further Information

Service contracts are not available. Calculator product circuitry and design are proprietary to Hewlett-Packard, and service manuals are not available to customers.

Should other problems or questions arise regarding repairs, please call your nearest Hewlett-Packard sales office or repair center.

Users' Library

For information concerning currently available HP bar code materials, please contact one of the following Hewlett-Packard Users' Libraries:

Hewlett-Packard S.A.
USERS' CLUB EUROPE
7, Rue du Bois-du Lan
P. O. Box, CH-1217 Meyrin 2
Geneva, Switzerland

Hewlett-Packard Company
USERS' LIBRARY
1000 N.E. Circle Blvd.
Corvallis, Oregon 97330
U.S.A.

Appendix C

Wand Accessories

Standard Wand Accessories

The following standard accessories are shipped with your HP 82153A Wand:

Accessory	HP Part Number
• <i>HP 82153A Wand Owner's Manual</i>	82153-90001
• <i>HP 82153A Wand Paper Keyboard</i>	82153-90008
• Standard Pressure-Sensitive Label Set (10 pages—more than 800 labels)	
• Three transparent protective sheets	

Optional Wand Accessory

In addition to the standard accessories shipped with your HP 82153A Wand, Hewlett-Packard also makes available the following optional publication for users who desire to generate their own bar code.

Creating Your Own HP-41C Bar Code (available Spring, 1981), HP part number 82153-90019.

Provides the detailed information needed to implement bar code production on computer-plotter or computer-printer systems. Includes coverage of HP bar code types and specifications, annotated computer BASIC language programs, flowcharts, general guidelines for implementation on various systems, and a discussion of HP bar code algorithms.

To order *Creating Your Own HP-41C Bar Code*, contact your nearest authorized Hewlett-Packard dealer or consult the accessory brochure included with your wand.

Appendix D

Bar Code for the HP-41C Standard Applications Pac

The bar code in this appendix corresponds to the program listings in the *HP-41C Standard Applications Pac Handbook* (revision B, November 1979).

This appendix includes the bar code needed to perform the following operations for each HP-41C Standard Applications program:

- Set the HP-41C to any special status conditions (SIZE, display settings, and flag settings) required by the program.
- Load the program. (If you place the HP-41C in USER mode before scanning the RPN Primer or Vector Operations program bar code, the key assignments indicated in the *HP-41C Standard Applications Pac Handbook* for those programs will also be made.)
- Execute the program (XEQ instructions are provided for all programs except the RPN Primer program).
- Following execution of the program, clear any flags set, but not cleared, by the program.


The Calendar Functions, Hexadecimal-Decimal Converter, and Financial Calculations programs begin with local labels (refer to section 12, Subroutines, in your *HP-41C Owner's Handbook and Programming Guide*). Local labels will not appear in the HP-41C's program catalog (press **CATALOG** 1 on the keyboard). If you want easier access to any of these programs, and you have sufficient space in program memory, insert a non-local (global) label of your choosing at the beginning of the desired program.

The bar coded flag commands that follow most of the program bar code listings are provided to normalize flags that may be left in a non-normal status following execution or partial execution of the programs.

NOTICE


The program material contained herein is supplied without representation or warranty of any kind. Hewlett-Packard Company therefore assumes no responsibility and shall have no liability, consequential or otherwise, of any kind arising from the use of this program material or any part thereof.

RPN Primer

**SIZE 1****FIX 0****SF 27 (Sets USER mode.)****CF 29**

PROGRAM REGISTERS NEEDED: 44


ROW 1 (1 - 4)



ROW 2 (4 - 9)



ROW 3 (9 - 14)



ROW 4 (15 - 20)



ROW 5 (21 - 27)



ROW 6 (28 - 33)



ROW 7 (34 - 39)



ROW 8 (39 - 44)



ROW 9 (44 - 50)



ROW 10 (50 - 57)



ROW 11 (57 - 60)



ROW 12 (60 - 64)



ROW 13 (64 - 68)



ROW 14 (69 - 72)



ROW 15 (73 - 77)



ROW 16 (77 - 81)



ROW 17 (81 - 84)



ROW 18 (85 - 90)



ROW 19 (90 - 93)



ROW 20 (93 - 97)



ROW 21 (97 - 102)



ROW 22 (102 - 107)



ROW 23 (108 - 112)



ROW 24 (112 - 113)



CF 05



SF 29

Calendar Functions



SIZE 10




FIX 4



SF 27 (Sets USER mode.)

PROGRAM REGISTERS NEEDED: 54

ROW 1 (1 - 9)



ROW 2 (10 - 16)



ROW 3 (17 - 22)



ROW 4 (22 - 28)



ROW 5 (29 - 40)



ROW 6 (41 - 53)



ROW 7 (54 - 61)



ROW 8 (62 - 69)



ROW 9 (70 - 78)



ROW 10 (79 - 88)



ROW 11 (89 - 100)



ROW 12 (100 - 108)



ROW 13 (108 - 116)



ROW 14 (117 - 124)



ROW 15 (125 - 134)



ROW 16 (135 - 142)



ROW 17 (143 - 148)



ROW 18 (149 - 153)



ROW 19 (153 - 157)



ROW 20 (157 - 160)



ROW 21 (160 - 163)



ROW 22 (163 - 166)



ROW 23 (166 - 172)



ROW 24 (172 - 178)



ROW 25 (178 - 183)



ROW 26 (184 - 188)



ROW 27 (189 - 193)



ROW 28 (194 - 199)



ROW 29 (199 - 203)



XEQ A



XEQ B



XEQ C



XEQ E



CF 06



CF 22



SF 28




SF 29

Word Guessing Game



SIZE 19



FIX 0



CF 29

PROGRAM REGISTERS NEEDED: 37

ROW 1 (1 - 2)



ROW 2 (2 - 6)



ROW 3 (7 - 10)



ROW 4 (10 - 12)



ROW 5 (13 - 14)



ROW 6 (14 - 17)



ROW 7 (17 - 23)



ROW 8 (23 - 31)



ROW 9 (31 - 39)



ROW 10 (40 - 47)



ROW 11 (48 - 55)



ROW 12 (56 - 62)



ROW 13 (63 - 70)



ROW 14 (70 - 74)



ROW 15 (74 - 77)




ROW 16 (78 - 82)



ROW 17 (82 - 84)



ROW 18 (84 - 87)



ROW 19 (88 - 95)



ROW 20 (96 - 99)



XEQ WORDS




R/S



SF 29


Arithmetic Teacher



SIZE 10



FIX 0



CF 29

PROGRAM REGISTERS NEEDED: 52

ROW 1 (1 - 3)



ROW 2 (4 - 6)



ROW 3 (6 - 11)



ROW 4 (12 - 17)



ROW 5 (17 - 23)



ROW 6 (23 - 27)



ROW 7 (28 - 31)



ROW 8 (32 - 37)



ROW 9 (37 - 43)



ROW 10 (43 - 49)



ROW 11 (49 - 55)



ROW 12 (56 - 58)



ROW 13 (59 - 67)




ROW 14 (67 - 73)



ROW 15 (73 - 77)



ROW 16 (78 - 86)



ROW 17 (86 - 93)



ROW 18 (94 - 103)



ROW 19 (103 - 111)



ROW 20 (111 - 118)



ROW 21 (118 - 122)



ROW 22 (122 - 131)



ROW 23 (131 - 135)



ROW 24 (135 - 141)



ROW 25 (142 - 147)



ROW 26 (147 - 152)



ROW 27 (153 - 159)



ROW 28 (160 - 164)



.021946



XEQ TEACH



R/S



SF 29



CF 00

Hexadecimal-Decimal Converter



SIZE 21



FIX 0



SF 27 (Sets USER mode.)

PROGRAM REGISTERS NEEDED: 37

ROW 1 (1 - 7)



ROW 2 (7 - 15)



ROW 3 (16 - 24)



ROW 4 (25 - 32)



ROW 5 (33 - 38)



ROW 6 (39 - 45)



ROW 7 (46 - 54)



ROW 8 (55 - 62)



ROW 9 (63 - 71)



ROW 10 (71 - 78)



ROW 11 (78 - 85)



ROW 12 (86 - 94)



ROW 13 (94 - 101)



ROW 14 (102 - 109)



ROW 15 (110 - 116)




ROW 16 (116 - 122)



ROW 17 (123 - 129)



ROW 18 (129 - 135)




ROW 19 (136 - 141)



ROW 20 (141 - 143)



XEQ A



XEQ E



ALPHA



CF 22



CF 23

Financial Calculations



PROGRAM REGISTERS NEEDED: 40

ROW 1 (1 - 11)



ROW 2 (12 - 21)



ROW 3 (22 - 31)



ROW 4 (32 - 42)



ROW 5 (43 - 54)




ROW 6 (55 - 67)



ROW 7 (68 - 76)



ROW 8 (76 - 88)



ROW 9 (89 - 101)



ROW 10 (102 - 110)



ROW 11 (110 - 117)



ROW 12 (118 - 126)



ROW 13 (126 - 134)



ROW 14 (134 - 142)




ROW 15 (142 - 152)



ROW 16 (152 - 159)



ROW 17 (160 - 169)



ROW 18 (169 - 176)



ROW 19 (177 - 189)



ROW 20 (190 - 198)



ROW 21 (198 - 199)



ROW 22 (199 - 202)



XEO a



XEO A



XEO B



XEO C



XEO D



XEO E



CF 22

Root Finder



SIZE 8



DEG



FIX 4

PROGRAM REGISTERS NEEDED: 21

ROW 1 (1 - 2)



ROW 2 (2 - 5)



ROW 3 (6 - 8)



ROW 4 (9 - 13)



ROW 5 (14 - 24)



ROW 6 (25 - 36)



ROW 7 (37 - 44)



ROW 8 (45 - 55)



ROW 9 (56 - 65)



ROW 10 (66 - 71)



ROW 11 (71 - 75)




XEQ ROOT



R/S

Curve Fitting



SIZE 16



ΣREG 10



FIX 2

PROGRAM REGISTERS NEEDED: 37

ROW 1 (1 - 4)



ROW 2 (4 - 7)



ROW 3 (8 - 11)



ROW 4 (11 - 15)



ROW 5 (15 - 20)



ROW 6 (20 - 30)



ROW 7 (30 - 41)



ROW 8 (42 - 51)



ROW 9 (52 - 61)



ROW 10 (62 - 72)



ROW 11 (73 - 85)



ROW 12 (86 - 92)



ROW 13 (92 - 102)



ROW 14 (103 - 113)



ROW 15 (113 - 121)



ROW 16 (122 - 132)



ROW 17 (133 - 141)



ROW 18 (142 - 147)



ROW 19 (147 - 153)




ROW 20 (153 - 156)




XEQ LIN



XEQ EXP



XEQ LOG



XEQ POW



ENTER+



XEQ A



XEQ C



XEQ E



XEQ a



R/S



CF 00



CF 01




CF 02



CF 21




CF 27



SF 29

Vector Operations



SIZE 00



SF 27 (Sets USER mode.)



FIX 2

PROGRAM REGISTERS NEEDED: 13

ROW 1 (1 - 6)



ROW 2 (6 - 12)



ROW 3 (13 - 15)



ROW 4 (16 - 20)



ROW 5 (20 - 32)



ROW 6 (33 - 36)




ROW 7 (36 - 40)



ENTER



XEQ CADD



XEQ CSUB



XEQ CMULT



XEQ CDIV

Blackjack



SIZE 27



FIX 0



CF 29

PROGRAM REGISTERS NEEDED: 89

ROW 1 (1 - 6)



ROW 2 (7 - 10)



ROW 3 (11 - 21)



ROW 4 (22 - 29)



ROW 5 (29 - 36)



ROW 6 (37 - 45)



ROW 7 (45 - 52)



ROW 8 (53 - 60)



ROW 9 (61 - 67)



ROW 10 (67 - 72)



ROW 11 (72 - 76)



ROW 12 (76 - 81)



ROW 13 (82 - 84)



ROW 14 (84 - 91)



ROW 15 (91 - 98)



ROW 16 (98 - 103)



ROW 17 (104 - 111)




ROW 18 (111 - 116)



ROW 19 (116 - 122)



ROW 20 (122 - 125)



ROW 21 (126 - 131)



ROW 22 (132 - 134)



ROW 23 (135 - 142)



ROW 24 (143 - 148)



ROW 25 (148 - 151)



ROW 26 (151 - 156)



ROW 27 (156 - 163)



ROW 28 (164 - 169)



ROW 29 (169 - 175)



ROW 30 (175 - 177)



ROW 31 (177 - 181)



ROW 32 (182 - 186)



ROW 33 (186 - 193)



ROW 34 (193 - 201)



ROW 35 (201 - 207)



ROW 36 (208 - 214)



ROW 37 (214 - 220)



ROW 38 (220 - 221)



ROW 39 (222 - 225)



ROW 40 (226 - 231)



ROW 41 (231 - 234)



ROW 42 (235 - 239)



ROW 43 (239 - 245)



ROW 44 (245 - 249)



ROW 45 (249 - 254)




ROW 46 (255 - 259)



ROW 47 (259 - 262)



ROW 48 (262 - 263)



ASN DL 11



ASN HT 12



ASN S 13



SF 27 (Sets USER mode.)




XEQ SH



STO 21



STO 00



XEO DL



XEO HT




XEO S



CF 00



CF 01



CF 02




CF 03



CF 04



CF 06



CF 07



CF 08



CF 09



SF 29



CF 22

Appendix E
Demonstration Programs

The HP 82153A Wand allows convenient entry of bar coded HP-41C programs, functions, and data. The utility of reading programs into your calculator from bar code listings is obvious; the following demonstration programs are intended to help you glimpse the potential of being able to read data and execute individual HP-41C functions from bar code.

“Search and Destroy” is a destroyer vs. submarine game typical of grid search games. The advantage of using the wand is that grid positions are simply scanned in as opposed to keyed in, eliminating the need to specify row and column numbers. Furthermore, commands to drop depth charges, etc. are scanned in from the “game board,” freeing the player from referring to user instructions or remembering key assignments.

“Character Builder” demonstrates the wand’s usefulness in another problem of a grid nature, only this time in a very practical application. Building special characters by specifying which of the forty-nine dots in the 7×7 printhead matrix will print and which will not is a somewhat cumbersome task without the wand. With it, just scan the desired “dots” on the grid and the program builds the character, instructing the corresponding dots in the printhead to print. You can quickly and easily make monograms, logos, or other special symbols.

“Triangle Solutions” illustrates how some problems can be structured to take advantage of very natural data entry and solution schemes using the wand. In this example, an infinity of triangles of any shape and size can be solved in the same straightforward way using the wand and a simple graphic aid.

And if you are having trouble reading bar code using the wand, or cannot read it at all, there is a very short program called “Pace” that will help you with your technique.

Search and Destroy

Imagine that you are the commander of a destroyer with orders to search out and destroy an enemy submarine. The submarine is somewhere in an area 10 leagues by 10 leagues. To find the submarine, input the position of your ship by scanning the bar code grid. From that position, you search for the submarine with your sonar, as indicated by the display and the initial tone. If the sub is within sonar range, there will be an echo, indicated by the display and a second tone. The pitch of the echo is determined by the distance to the submarine—the higher the pitch, the closer the submarine.

Attempt to move your destroyer directly over the sub for an attack by scanning the grid. Then scan the bar code to “DROP DEPTH CHARGES.” If you are directly over the submarine, you will sink it. If you are within 1.5 leagues, there is a chance you will sink it.

A successful attack is indicated by **BOOM** appearing in the display. Otherwise **MISSED** will be displayed and the submarine will have moved. Its new location will be within a radius of one league from its last position.

To play, the steps are as follows:

1. Execute the program memory **SIZE** command and load the program by scanning the bar code on page 61.
2. Scan the **XEO** SG barcode.
The display will prompt you with **SEED**.
3. Key in any integer number, and then scan "BEGIN".
4. The display will prompt you with **ORDERS? nm** where *n* is the row and *m* is the column of the last position scanned (initially 0). Search for the submarine, moving the destroyer to any location on the grid by scanning the bar code for that position. You'll hear the sonar pulse go out. If you're within range of the sub (within 2.5 leagues) you'll hear an echo, the higher the pitch, the closer the sub.
5. Alternatively, you can "DROP DEPTH CHARGES" or check the "STATUS" to determine how many soundings you have made and how many depth charges you have dropped.

Example:

Operation
Scan **XEO** SG

Display
SEED?

Key in the integer seed 73,
then scan BEGIN

ORDERS 0

First move:

Scan 55

SCANNING (no echo)
ORDERS 55


Since there was no echo, eliminate the shaded region below.

Second move:

Scan 22

SCANNING (low pitch echo)
CONTACT
ORDERS 22

Since a low pitch echo sounded, eliminate the area very close to the ship's location.




Third move:

Scan 20

SCANNING (high pitch echo)
CONTACT
ORDERS 20

Since a high pitch echo sounded, the sub is close. Scan DROP DEPTH CHARGES.

BOOM
1 CAN
3 SCANS
GOOD JOB
NEW GAME
ORDERS 0



0	1	2	3	4	5	6	7	8	9	BEGIN	XEO SG
10	11	12	13	14	15	16	17	18	19		
20	21	22	23	24	25	26	27	28	29		
30	31	32	33	34	35	36	37	38	39		
40	41	42	43	44	45	46	47	48	49		
50	51	52	53	54	55	56	57	58	59		
60	61	62	63	64	65	66	67	68	69		
70	71	72	73	74	75	76	77	78	79	STATUS	DROP DEPTH CHARGES
80	81	82	83	84	85	86	87	88	89		
90	91	92	93	94	95	96	97	98	99		

Character Builder

Here's a slick application for your wand. If you've ever tried building special characters on the 82143A Printer using **BLDSPEC**, you know how long it takes to specify which dots in the 7×7 matrix to turn on and which to leave off. Using this program and the 6×6 matrix of specialized bar code on the facing page, a corresponding 6×6 dot matrix character can be built by simply scanning the "dots" that are to be turned on. The specialized bar code "dots" are simply two digit numbers, 11 through 66, that comprise the row and column information.

Notes:

1. Because of printer buffer limitations, a 6×6 matrix is used rather than a 7×7 matrix.
2. To run this program a printer and one memory module are required.

Instructions:

1. **[SIZE]** memory and load the program by scanning the bar code on page 63.
2. Using the graphic aid on the facing page, scan **[XEQ] CRBLD**.
3. When the prompt **W: READY** is displayed, scan any element of the matrix that is to be incorporated into the special character.
4. Repeat step 3 until all "dots" are specified. Then scan **STOP**; the finished character will be printed together with a super graphic of the character.

Example:

Use the wand to build a "flying goose."

SOLUTION:

SPECIAL CHARACTER





XEO CRBLD



STOP

Triangle Solutions

Given three sides of a triangle or a combination of sides and angles, this program solves for the remaining sides and angles and computes the area of the triangle. There are no keystrokes required—everything can be accomplished with the wand and the graphic aid on the facing page. Simply scan the values for the sides or angles together with the bar code for the corresponding sides or angles in the diagram, in any order, until all of the known values are input. Then scan the code for any of the sides or angles in the diagram to display their lengths or measures. Scanning the bar code labeled **AREA** displays the computed area of the triangle.


Notes:

1. If a triangle cannot exist with the side lengths and angle measures given, i.e., the data is inconsistent, **DATA ERROR** will be displayed.
2. In some cases, two solutions exist because one of the angles can be either obtuse or acute. Both solutions will be displayed.
3. The equations used are derived from the Law of Sines and the Law of Cosines.

Instructions:

1. **SIZE** memory and load the program by scanning the bar code on page 65.
2. Using the graphic aid on the facing page, scan **XEQ TRI**.
3. Scan the numeric value for any known part of the triangle followed by the bar code for the part. Angles are measured in degrees.
4. Repeat step 3 until all data are entered. A minimum of three known parts is required, but if additional information is known, more than three parts may be entered and execution time will be shortened.
5. Scan the bar code for the area or any side or angle to display its calculated value.
6. For another triangle, go to step 3.

Example: Solve the triangle below.



```

        XEQ "TRI"
        7.0000 XEQ c
        c=7.0000      5.0000 XEQ a
        a=5.0000      36.0000 XEQ A
        A=36.0000      XEQ b
        XEQ b
    
```

```

        SOLUTION 1
        b=8.5041
    
```

```


        SOLUTION 2
        b=2.8222
        XEQ D
    
```

```


        SOLUTION 1
        AREA=17.4950
        SOLUTION 2
        AREA=5.8059
        XEQ C
    
```

```


        SOLUTION 1
        A=55.3761
        SOLUTION 2
        A=124.6239
    
```



1st solution



2nd solution



Pace

This short program is intended to help new wand users surmount an obstacle many encounter when learning to read bar code—scanning too slowly.

First remove the wand from the HP-41C, set program mode, and key in the following:

```
■ [LBL] [ALPHA] PACE [ALPHA]  
■ [LBL] 01  
XEQ [ALPHA] PSE [ALPHA]  
XEQ [ALPHA] TONE [ALPHA] 7  
■ [GTO] 01
```

Then take the HP-41C out of program mode and press **R/S**. Turn to a page of program bar code, and although you won't actually be reading anything into the calculator, sweep the wand across the rows using the programmed tone to pace yourself. The rate at which you must move the wand to scan one row per tone is an indication of the rate required to successfully read bar code—much slower and the wand won't process the bar code.

Turn off the calculator and plug the wand into an empty port. Now that you have a feeling for how fast to scan bar code, try it!

Search and Destroy

PROGRAM REGISTERS NEEDED: 55



SIZE 008

ROW 1 (1 - 4)



ROW 2 (4 - 12)



ROW 3 (13 - 19)



ROW 4 (19 - 22)




ROW 5 (23 - 31)



ROW 6 (31 - 32)



ROW 7 (33 - 39)



ROW 8 (40 - 48)



ROW 9 (49 - 50)



ROW 10 (51 - 58)



ROW 11 (59 - 64)



ROW 12 (65 - 71)



ROW 13 (72 - 76)



ROW 14 (76 - 84)



ROW 15 (84 - 88)



ROW 16 (89 - 93)

ROW 17 (94 - 100)



ROW 18 (100 - 108)



ROW 19 (108 - 112)



ROW 20 (112 - 118)



ROW 21 (118 - 126)



ROW 22 (127 - 132)



ROW 23 (132 - 140)



ROW 24 (140 - 148)



ROW 25 (149 - 159)



ROW 26 (160 - 165)



ROW 27 (165 - 166)



ROW 28 (166 - 171)



ROW 29 (171 - 176)



ROW 30 (177 - 178)



Character Builder
PROGRAM REGISTERS NEEDED: 35



SIZE 041

ROW 1 (1 - 4)



ROW 2 (5 - 11)



ROW 3 (12 - 19)



ROW 4 (20 - 30)



ROW 5 (31 - 41)



ROW 6 (41 - 44)



ROW 7 (44 - 47)



ROW 8 (47 - 53)



ROW 9 (53 - 60)



ROW 10 (61 - 70)



ROW 11 (71 - 78)



ROW 12 (79 - 85)



ROW 13 (86 - 93)



ROW 14 (93 - 98)




ROW 15 (99 - 105)



ROW 16 (105 - 111)



ROW 17 (112 – 118)



ROW 18 (118 – 120)



ROW 19 (120 – 121)



Triangle Solutions

PROGRAM REGISTERS NEEDED: 94



SIZE 030

ROW 1 (1 - 5)



ROW 2 (5 - 9)



ROW 3 (9 - 14)



ROW 4 (15 - 18)



ROW 5 (18 - 23)



ROW 6 (24 - 27)



ROW 7 (27 - 33)



ROW 8 (33 - 36)



ROW 9 (36 - 42)



ROW 10 (42 - 45)



ROW 11 (46 - 49)



ROW 12 (50 - 53)



ROW 13 (53 - 55)



ROW 14 (55 - 57)



ROW 15 (57 - 61)

ROW 16 (61 - 64)



ROW 17 (64 - 69)



ROW 18 (69 - 70)



ROW 19 (70 - 74)



ROW 20 (75 - 79)



ROW 21 (80 - 82)



ROW 22 (82 - 87)



ROW 23 (87 - 89)



ROW 24 (90 - 97)



ROW 25 (98 - 104)



ROW 26 (105 - 109)



ROW 27 (109 - 114)



ROW 28 (114 - 118)



ROW 29 (118 - 124)



ROW 30 (124 - 128)



ROW 31 (129 - 135)



ROW 32 (135 - 138)



ROW 33 (138 - 140)



ROW 34 (141 - 147)



ROW 35 (147 - 152)



ROW 36 (153 - 159)



ROW 37 (160 - 166)



ROW 38 (167 - 171)



ROW 39 (172 - 184)




ROW 40 (185 - 194)




ROW 41 (195 - 205)



ROW 42 (205 - 215)



ROW 43 (216 - 226)



ROW 44 (227 - 236)



ROW 45 (237 - 248)



ROW 46 (249 - 259)



ROW 47 (259 - 270)



ROW 48 (270 - 279)



ROW 49 (280 - 292)



ROW 50 (293 - 305)



ROW 51 (306 - 310)




Pace

PROGRAM REGISTERS NEEDED: 3

ROW 1 (1 - 5)



ROW 2 (5 - 6)



HP 82153A Wand Function Index

When the HP 82153A Wand is plugged into the HP-41C, the following functions become active in the system. These functions and programs containing these functions are only executable while the wand is plugged in. You can list all of these functions by executing **CATALOG** 2.

- WNDDTA** Scan one row of data bar code.
- WNDDTX** Scan and store one or more rows of data bar code as directed by X.
- WNDLNK** Scan and execute a bar coded subroutine.
- WNDSUB** Scan a bar coded subroutine.
- WNDSCN** Scan a row of specialized bar code for control of user-defined functions.
- WNDTST** Scan a row of bar code to test for correct reads of the bar code.



1000 N.E. Circle Blvd., Corvallis, OR 97330, U.S.A.

Scan Copyright ©
The Museum of HP Calculators
www.hpmuseum.org

Original content used with permission.

Thank you for supporting the Museum of HP
Calculators by purchasing this Scan!

Please do not make copies of this scan or
make it available on file sharing services.