HP-01 Reference Guide

(T) TIME

To display: (T)

To set: HH:MM:SS (p) (or (▲)(a)) (▲)(T)

To adjust time: (T)(+) (or (−)) HH (or HH:MM:SS) (▲)(T)

To change time display modes: (T)(▲)(•)

To convert to and from decimal hours: (▲)(T▸) , (▲)(▸T)

To calculate with time: (T) (or HH:MM:SS)
(+) (or (−)) HH:MM:SS (=)

(A) ALARM

To display: (A)

To set: HH:MM:SS (p) (or (▲)(a)) (▲)(A)

To reset/disable: (A)(▲)(A)

(S) TIMER/STOPWATCH

To display timer/stopwatch: (S)

To set timer: HH:MM:SS (or MM:SS.CC) (▲)(S)

If timer/stopwatch is displayed and stopped,

To reset to zero: (R)

To start: (S)

Dynamic calculations: (S)(×) (or (÷)) hourly rate (=)

If timer/stopwatch is displayed and running,

To take a split: (R) (or (▲)(M)), to return to timer/stopwatch display: (S)

To stop: (S)

To inhibit display: (T), to return to timer/stopwatch display: (S), to return to dynamic calculation: (S)(=)

D DATE/CALENDAR

To display: D

To set: MM/DD/YY (or DD/MM/YY) ▲ D

Century 21: follow date with ▲ 21

To change date display modes: D ▲ .

Future or past date: D (or MM/DD/YY) + (or −) number-of-days =

Days between dates: MM/DD/YY − MM/DD/YY =

Day of week: ▲ DW

Day of year: ▲ /

CALCULATOR

Arithmetic: number + (or −, ×, ÷) number =

Automatic constant: number + (or −, ×, ÷) constant =, new number =, new number = etc.

Change sign: ▲ −/+

Exchange numbers: ▲ ⇄

Net amount: base amount + (or −) number % =

Percentage: base number × number % =

Percent: number ÷ base number % =

To clear calculator: C C

M MEMORY

To display: M

To store: ▲ M

DISPLAY

To recall: R

To clear entry: C

HEWLETT hp PACKARD

00001-90002
Rev. B 8/77

Printed in U.S.A.

© Hewlett-Packard Company, 1977

Scan Copyright ©
The Museum of HP Calculators
www.hpmuseum.org

Original content used with permission.

Thank you for supporting the Museum of HP Calculators by purchasing this Scan!

Please to not make copies of this scan or make it available on file sharing services.